

## Evergrain Acoustic Wall Panel Installation Guide:

Thank you for choosing Evergrain Acoustic Wall Paneling to enhance your space. Follow these simple steps for a flawless installation:

1. **Preparation and Usage:** Evergrain Acoustic Wall Panels are perfect for hallways, living rooms, dining areas, bedrooms, and offices. Avoid areas prone to moisture or flames, such as kitchens and around fireplaces.
2. **Storage and Handling:** Handle panels with care to prevent edge damage. Store them flat on the floor or leaned against a wall with spacers. Protect panels from damage and dust if not installing immediately.
3. **Cutting Instructions:**
  - Always cut from the wood slat side.
  - Mark cut lines with a pencil and use masking tape to prevent chipping.
  - Use a fine-tooth saw or circular saw, guiding it slowly to avoid damaging edges.
  - Clamp a straight edge when using a circular saw for a smooth cut.
  - Remove masking tape and residue after cutting.
4. **Installing Panels:**
  - Lay the panel with battens facing down on a soft surface to protect wooden slats.
  - Apply Sika Flex T-55 adhesive in evenly spaced, 20mm-wide sections from left to right or side to side of the board. Ensure one line along the top and one along the bottom edge, evenly distributing three more lines of adhesive across the board for consistent bonding.
  - Position the panel against the wall, ensuring the bottom aligns with the wall bottom.
  - Press the panel into place and screw it if necessary. Use screws for stacked panels or ceiling installations.

With these steps, installing Evergrain Acoustic Wall Panels will be a straightforward and rewarding DIY project, adding both style and functionality to your space. Enjoy your newly transformed walls!